



Capacitive Fingerprint Reader



R20 R18 C3 C7 R2



R22 R21 C9 R1 R4 R6



R5 R14

C1 C2

C6 R11

C8 U1

R21 R28

R23 U3

R25 C11

C10

C12 R26

R17 R19

U3


D1 D4

R16 R27

R24 R15

Q4

Q3



J3

