










USB




WIFI
ESP32-P4-WIFI6-Touch-LCD-4.3




BATTERY

ADC




BOOT

RESET




Back Light

RTC BAT




4.3 INCH




Codec


ADC




PA&SPEAKER&MIC



MIC



Interface



ESP32-P4-WIFI6-Touch-LCD-4.3

GND 52 51 50 49 35 34 GND 31 30 29 3V3 28 4 3 GND 2 SCLSDA 3V3
 48 47 46 GND 32 GND DP DM 25 24 GND 22 21 GND 5 38 37 GND 5V 5V

