




LSK2

Key1

RESET

Key2

BOOT


H10

H8


H11

H9

LSK1



RTC




SPK

3V3
GND
IO2
IO3
IO4
IO5
IO28
IO29
IO30
IO31
IO34
IO36

MIC1




I2C
SCL
SDA
GND
VCC






UART
TXD
RXD
GND
VCC


NC 120R
CAN
RS485




RS485
B
A
GND
5V




1024x600 Pixels
ESP32-P4-WIFI6-Touch-LCD-7B





TF Card





JLCJLCJLCJLC




CAMERA



BAT



U1





C6-UART

ON OFF




STAT




USB-OTG




J1




USB



H2



USB TO UART



H1



MIC2

LSK3