




Power




Interface



GNSS



GNSS Backup Power



Indicator light

W
aveshare
LC76G GNSS Module