


RP2350	OLED	SD Card	IMU	RTC	Other	GPIO OUT
GPIO0					TXD	TXD
GPIO1					RXD	RXD
GPIO2		SD_SCLK				GPIO2
GPIO3		SD_MOSI				GPIO3
GPIO4		SD_MISO				GPIO4
GPIO5		SD_CS				GPIO5
GPIO6	TP_SDA		IMU_SDA	RTC_SDA	DC_SDA	SDA
GPIO7	TP_SCL		IMU_SCL	RTC_SCL	DC_SCL	SCL
GPIO8			IMU_INT			
GPIO9				RTC_INT		
GPIO10	OLED_SCLK					
GPIO11	OLED_MOSI					
GPIO12	OLED_RS					
GPIO13	OLED_CS					
GPIO14	OLED_RST					
GPIO15	TP_INT					
GPIO16	TP_RST					
GPIO17						GPIO17
GPIO18						GPIO18
GPIO19						GPIO19
GPIO20						GPIO20
GPIO21						GPIO21
GPIO22						GPIO22
GPIO23						GPIO23
GPIO24						GPIO24
GPIO25						GPIO25
GPIO26					BAT_ADC	
GPIO27						GPIO27
GPIO28						GPIO28
GPIO29	OLED_PWR					GPIO29



**W** inohare

RP2350-Touch-AMOLED-1.43