



# SIM82XX\_SIM83XX Series \_HTTP(S)\_Application Note

5G Module

## **SIMCom Wireless Solutions Limited**

SIMCom Headquarters Building, Building 3, No. 289  
Linhong Road, Changning District, Shanghai P.R. China

Tel: 86-21-31575100

[support@simcom.com](mailto:support@simcom.com)

[www.simcom.com](http://www.simcom.com)

<b>Document Title: :</b>	SIM82XX_SIM83XX Series_HTTP(S)_Application Note
<b>Version:</b>	1.01
<b>Date:</b>	2021.11.25
<b>Status:</b>	Released

## GENERAL NOTES

SIMCOM OFFERS THIS INFORMATION AS A SERVICE TO ITS CUSTOMERS, TO SUPPORT APPLICATION AND ENGINEERING EFFORTS THAT USE THE PRODUCTS DESIGNED BY SIMCOM. THE INFORMATION PROVIDED IS BASED UPON REQUIREMENTS SPECIFICALLY PROVIDED TO SIMCOM BY THE CUSTOMERS. SIMCOM HAS NOT UNDERTAKEN ANY INDEPENDENT SEARCH FOR ADDITIONAL RELEVANT INFORMATION, INCLUDING ANY INFORMATION THAT MAY BE IN THE CUSTOMER'S POSSESSION. FURTHERMORE, SYSTEM VALIDATION OF THIS PRODUCT DESIGNED BY SIMCOM WITHIN A LARGER ELECTRONIC SYSTEM REMAINS THE RESPONSIBILITY OF THE CUSTOMER OR THE CUSTOMER'S SYSTEM INTEGRATOR. ALL SPECIFICATIONS SUPPLIED HEREIN ARE SUBJECT TO CHANGE.

## COPYRIGHT

THIS DOCUMENT CONTAINS PROPRIETARY TECHNICAL INFORMATION WHICH IS THE PROPERTY OF SIMCOM WIRELESS SOLUTIONS LIMITED COPYING, TO OTHERS AND USING THIS DOCUMENT, ARE FORBIDDEN WITHOUT EXPRESS AUTHORITY BY SIMCOM. OFFENDERS ARE LIABLE TO THE PAYMENT OF INDEMNIFICATIONS. ALL RIGHTS RESERVED BY SIMCOM IN THE PROPRIETARY TECHNICAL INFORMATION, INCLUDING BUT NOT LIMITED TO REGISTRATION GRANTING OF A PATENT , A UTILITY MODEL OR DESIGN. ALL SPECIFICATION SUPPLIED HEREIN ARE SUBJECT TO CHANGE WITHOUT NOTICE AT ANY TIME.

### **SIMCom Wireless Solutions Limited**

SIMCom Headquarters Building, Building 3, No. 289 Linhong Road, Changning District, Shanghai P.R. China

Tel: +86 21 31575100

Email: [simcom@simcom.com](mailto:simcom@simcom.com)

### **For more information, please visit:**

<https://www.simcom.com/download/list-863-en.html>

### **For technical support, or to report documentation errors, please visit:**

<https://www.simcom.com/ask/> or email to: [support@simcom.com](mailto:support@simcom.com)

**Copyright © 2021 SIMCom Wireless Solutions Limited All Rights Reserved.**

# About Document

## Version History

Version	Date	Owner	What is new
V1.00	2020.3.23	Xianxiang Ma	First Release
V1.01	2021.11.25	Xianxiang Ma	Update format

## Scope

This document applies to the SIMCom SIM820X series, SIM821X series, SIM826X series and SIM83XX series.

# Contents

<b>About Document.....</b>	<b>3</b>
Version History.....	3
Scope.....	3
<b>Contents.....</b>	<b>4</b>
<b>1 Introduction.....</b>	<b>5</b>
1.1 Purpose of the document.....	5
1.2 Related documents.....	5
1.3 Conventions and abbreviations.....	5
<b>2 HTTP Introduction.....</b>	<b>6</b>
2.1 Characteristic.....	6
2.2 Request Method.....	6
<b>3 AT Commands for HTTP(S).....</b>	<b>8</b>
<b>4 Bearer Configuration.....</b>	<b>9</b>
4.1 PDN Auto-activation.....	9
<b>5 HTTP(S) Examples.....</b>	<b>11</b>
5.1 HTTP Function.....	11
5.1.1 HTTP GET.....	11
5.1.2 Send HTTP POST Request.....	12
5.1.3 Send HTTP HEAD Request.....	13
5.2 Access to HTTPS server.....	14
5.2.1 Send HTTPS GET Request.....	14
5.2.2 Send HTTPS POST Request.....	15
5.2.3 Send HTTPS HEAD Request.....	16
5.2.4 POST FILE to HTTPS server and read HTTPS response content to a file.....	17

# 1 Introduction

## 1.1 Purpose of the document

Based on module AT command manual, this document will introduce HTTP(S) application process. Developers could understand and develop application quickly and efficiently based on this document.

## 1.2 Related documents

[1] SIM82XX\_SIM83XX Series\_AT Command Manual

## 1.3 Conventions and abbreviations

In this document, the GSM engines are referred to as following term:

ME (Mobile Equipment);

MS (Mobile Station);

TA (Terminal Adapter);

DCE (Data Communication Equipment) or facsimile DCE (FAX modem, FAX board);

In application, controlling device controls the GSM engine by sending AT Command via its serial interface.

The controlling device at the other end of the serial line is referred to as following term:

TE (Terminal Equipment);

DTE (Data Terminal Equipment) or plainly "the application" which is running on an embedded system;

## 2 HTTP Introduction

HTTP (HyperText Transfer Protocol) is an application layer protocol. When you browse a web page, the browser and the web server will send and receive data on the Internet through the HTTP protocol. HTTP is a stateless protocol based on request and response patterns. That is what we usually call Request/Response.

### 2.1 Characteristic

#### ➤ Support client/server mode;

##### ✧ Simple and fast

When a client requests a service from a server, it only needs to pass the request method and path. Because the HTTP protocol is simple, the program size of the HTTP server is small, and the communication speed is fast.

##### ✧ Flexible

HTTP allows the transfer of any type of data object. The type being transferred is marked by Content-Type;

##### ✧ No connection

No connection means limiting the processing of only one request per link. After the server processes the client's request and receives the customer's response, the server disconnects the link. This way, the transmission time can be saved.

##### ✧ Stateless

The HTTP protocol is a stateless protocol. Stateless means that the protocol has no memory for transaction processing. A lack of state means that if subsequent processing requires the previous information, it must be retransmitted, which may result in an increase in the amount of data transferred per connection. On the other hand, it responds faster when the server does not need previous information.

### 2.2 Request Method

According to the HTTP standard, HTTP requests can use a variety of request methods.

HTTP 1.0 defines three request methods: the GET, POST, and HEAD methods.

HTTP1.1 adds six new request methods: OPTIONS, PUT, PATCH, DELETE, TRACE, and CONNECT

methods.

No	Method	Description
1	GET	Make a request to a specific resource.
2	HEAD	Ask the server for a response that is consistent with the GET request, except that the response body will not be returned. This method can obtain the meta information contained in the response message header without having to transmit the entire response content.
3	POST	Submit data to a specified resource for processing requests (such as submitting a form or uploading a file). The data is included in the request body. POST requests may result in the creation of new resources and/or modifications to existing resources.
4	PUT	Uploads its latest content to a specified resource location.
5	DELETE	Requests the server to delete the resource identified by the Request-URI.
6	CONNECT	H The HTTP/1.1 protocol is reserved for proxy servers that can connect connections to pipes.
7	OPTIONS	Returns the HTTP request method supported by the server for a particular resource. You can also test the functionality of the server by sending a '*' request to the web server.
8	TRACE	Echoes requests received by the server, primarily for testing or diagnostics.
9	PATCH	It is a supplement to the PUT method for local updating of known resources.

The SIM8200 series supports several methods: GET, POST and HEAD.

## 3 AT Commands for HTTP(S)

Command	DESCRIPTION
AT+HTTPPARA	Set HTTP(S) Parameter
AT+HTTPINIT	Start HTTP(S) service
AT+HTTPACTION	HTTP(S) Method Action
AT+HTTPHEAD	Read the HTTP Header Information of Server Response
AT+HTTPREAD	Read the response Information of Server Response
AT+HTTPDATA	You can use AT+HTTPDATA to input data to post when you send a HTTP/HTTPS POST request
AT+HTTPPOSTFILE	Send HTTP request in a file via AT+HTTPPOSTFILE command
AT+HTTPREADFILE	Receive HTTP Response Content to a file
AT+HTTPTERM	Stop HTTP service.

For detail information, please refer to "SIM82XX\_SIM83XX\_Series\_AT Command Manual".



## 4 Bearer Configuration

Usually module will register PS service automatically.

### 4.1 PDN Auto-activation

#### AT+CPIN?

+CPIN: READY // Check Status of SIM Card

OK

#### AT+CSQ

+CSQ: 27,99 // Check RF Signal

OK

#### AT+CGREG?

+CGREG: 0,1 // Check Status of PS Service

OK

#### AT+CEREG?

+CEREG: 0,1

OK

#### AT+COPS?

+COPS: 0,0,"CHN-UNICOM",13 // Check Information of Operator

OK

#### AT+CPSI?

+CPSI: NR5G\_SA,Online,460-00,0x161816,13190066179,476,NR5G  
\_BAND41,504990,-1130,-140,30 // Check Information of Network

OK

AT+CGDCONT=1, "IP", "CMNET" // Set PDP context Parameters

OK

#### AT+CGDCONT?

+CGDCONT:  
1,"IPV4","CMNET","0.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0",0,0,0,0 // Check Information of PDP Context

OK

SIMCom  
Confidential

## 5 HTTP(S) Examples

### 5.1 HTTP Function

#### 5.1.1 HTTP GET

// Following commands shows how to send a HTTP GET request to server, and how to read HTTP response.

```
AT+HTTPINIT // start HTTP service, activate PDP context
OK
AT+HTTTPARA="URL","http://opinion.people.com.cn/GB/n1/2018/0815/c1003-30228758.htm" // set the URL which will be accessed, for HTTP,
// the request URL begins with "HTTP://"
OK
AT+HTTPACTION=0 // send HTTP GET request
OK // 22505 is the length of HTTP response
// information
+HTTPACTION: 0,200,22505
AT+HTTPHEAD // read the HTTP response header
+HTTPHEAD: DATA,387
HTTP/1.1 200 OK
Server: nginx
Content-Type: text/html
Connection: close
Date: Thu, 16 Aug 2018 05:13:36 GMT
Powered-By-ChinaCache: MISS from
06053423gG.15
ETag: W/"5b7379f5-57e9"
Last-Modified: Wed, 15 Aug 2018 00:55:17
GMT
Expires: Thu, 16 Aug 2018 05:18:36 GMT
Vary: Accept-Encoding
X-Cache-Hits: 14
Content-Length: 22505
CC_CACHE: TCP_REFRESH_HIT
Accept-Ranges: bytes
```

```
OK
AT+HTTPREAD=0,16 // read 16 bytes form response data
OK //data content: <!DOCTYPE html P

+HTTPREAD: DATA,16
<!DOCTYPE html P
+HTTPREAD: 0
AT+HTTPTERM // stop HTTP Service
OK
```

### 5.1.2 Send HTTP POST Request

```
// HTTP POST and PUT

AT+HTTPINIT // start HTTP service, activate PDP context
OK
AT+HTTPPARA="URL","http://api.efxnow.com/ //set the URL which will be accessed, for HTTP,
DEMOWebServices2.8/Service.asmx/Echo?" the request URL begins with "HTTP://"
```

Content-Length: 30	
OK	
<b>AT+HTTPTERM</b>	// stop HTTP Service
OK	

### 5.1.3 Send HTTP HEAD Request

```
// HTTP HEAD

AT+HTTPINIT // start HTTP service, activate PDP context
OK

AT+HTTPPARA="URL","http://opinion.people.com.cn/GB/n1/2018/0815/c1003-30228758.html" // set the URL which will be accessed, for HTTP, the request URL begins with "HTTP://"
OK

AT+HTTPACTION=2 //send a HEAD request to server to only get header of HTTP response
OK

+HTTPACTION: 2,200,387

+HTTP_PEER_CLOSED

AT+HTTPHEAD // read the HTTP response header
+HTTPHEAD: DATA,387
HTTP/1.1 200 OK
Server: nginx
Content-Type: text/html
Connection: close
Vary: Accept-Encoding
Powered-By-ChinaCache: MISS from 06053423gG.15
ETag: W/"5b7379f5-57e9"
Last-Modified: Wed, 15 Aug 2018 00:55:17 GMT
Content-Length: 22505
X-Cache-Hits: 14
Date: Thu, 16 Aug 2018 10:58:00 GMT
Expires: Thu, 16 Aug 2018 11:03:00 GMT
CC_CACHE: TCP_REFRESH_HIT
Accept-Ranges: bytes
```

```
OK
AT+HTTPTERM // stop HTTP Service
OK
```

## 5.2 Access to HTTPS server

### 5.2.1 Send HTTPS GET Request

```
//HTTPS GET

AT+HTTPINIT //start HTTP service, activate PDP context
OK
AT+HTTPPARA="URL","https://ss0.bdstatic.co // set the URL which will be accessed, for HTTPS,
m/5aV1bjqh_Q23odCf/static/mancard/css/card_ the request URL begins with "HTTPS:/"
min_dee38e45.css"
OK
AT+HTTPACTION=0 // send HTTPS GET request
OK

+HTTPACTION: 0,200,52060
AT+HTTPHEAD // read HTTPS response header
+HTTPHEAD: DATA,390 //390 is the length of HTTPS response header
HTTP/1.1 200 OK
Server: bfe/1.0.8.13-sslpool-patch
Date: Thu, 16 Aug 2018 11:38:08 GMT
Content-Type: text/css
Content-Length: 52060
Connection: close
ETag: "5a323f72-cb5c"
Last-Modified: Thu, 14 Dec 2017 09:08:02 GMT
Expires: Sat, 18 Aug 2018 09:50:53 GMT
Age: 2425635
Accept-Ranges: bytes
Cache-Control: max-age=2592000
Vary: Accept-Encoding
Ohc-Response-Time: 1 0 0 0 0
```

<pre> OK AT+HTTPREAD=0,24 OK  +HTTPREAD: DATA,24 .s-cardsetting{position: +HTTPREAD: 0 AT+HTTPTERM OK </pre>	<pre> // stop HTTP Service </pre>
--	-----------------------------------

## 5.2.2 Send HTTPS POST Request

<pre> //HTTPS POST AT+HTTPINIT OK AT+HTTTPARA="URL","https://pv.csdn.net/csdnbi" OK AT+HTTPDATA=465,1000 DOWNLOAD [{"headers":{"component":"enterprise","datatype":"track","version":"v1"},"body":{"url":"uid=merry1996&amp;ref=https%3A%2F%2Fpassport.csdn.net%2Faccount%2Fverify%3Bjsessionid%3D7895A57BC64CE8616517F558940FD913.tomcat2&amp;pid=www&amp;mod=&amp;con=&amp;ck=-&amp;curl=https%3A%2F%2Fwww.csdn.net%2F&amp;session_id=10_1534696351647.160829&amp;tos=12&amp;referrer=https%3A%2F%2Fpassport.csdn.net%2Faccount%2Fverify%3Bjsessionid%3D7895A57BC64CE8616517F558940FD913.tomcat2&amp;user_name=merry1996&amp;type=pv\""}]}] OK </pre>	<pre> //start HTTP service, activate PDP context  // set the URL which will be accessed, for HTTPS, the request URL begins with "HTTPS://"  // send data to post, the length is 465 bytes </pre>
<pre> AT+HTTPACTION=1 OK </pre>	<pre> //send HTTPS post request  //2 is the length of HTTPS response information </pre>
<pre> +HTTPACTION: 1,200,2  +HTTP_PEER_CLOSED AT+HTTPHEAD +HTTPHEAD: DATA,377 </pre>	<pre> //read the HTTPS response header </pre>

```

HTTP/1.1 200 OK
Server: openresty
Date: Mon, 20 Aug 2018 03:20:30 GMT
Content-Type: application/octet-stream
Connection: close
Set-Cookie:
uuid_tt_dd=10_37481894210-1534735230305-44
5993; Expires=Thu, 01 Jan 2025 00:00:00 GMT;
Path=/; Domain=.csdn.net;
Set-Cookie:
dc_session_id=10_1534735230305.501284;
Expires=Thu, 01 Jan 2025 00:00:00 GMT;
Path=/; Domain=.csdn.net;

OK
AT+HTTPTERM
OK
// stop HTTP Service

```

### 5.2.3 Send HTTPS HEAD Request

```

// HTTPS HEAD

AT+HTTPINIT //start HTTP service, activate PDP context
OK

AT+HTTTPARA="URL","https://ss0.bdstatic.com/5aV1bjqh_Q23odCf/static/mancard/css/card_min_dee38e45.css" //set the URL which will be accessed, for HTTPS, the request URL begins with "HTTPS://"
OK

AT+HTTPACTION=2 // send HTTPS HEAD request
OK

+HTTPACTION: 2,200,390

+HTTP_PEER_CLOSED

AT+HTTPHEAD // read HTTPS response header
+HTTPHEAD: DATA,390
HTTP/1.1 200 OK
Server: bfe/1.0.8.13-sslpool-patch
Date: Thu, 16 Aug 2018 11:46:22 GMT
Content-Type: text/css
Content-Length: 52060

```



```

Connection: close
ETag: "5a323f72-cb5c"
Last-Modified: Thu, 14 Dec 2017 09:08:02 GMT
Expires: Sat, 18 Aug 2018 09:50:53 GMT
Age: 2426129
Accept-Ranges: bytes
Cache-Control: max-age=2592000
Vary: Accept-Encoding
Ohc-Response-Time: 1 0 0 0 0

```

```

OK
AT+HTTPTERM //stop HTTP Service
OK

```

#### 5.2.4 POST FILE to HTTPS server and read HTTPS response content to a file

```

// HTTPS POST/PUT

AT+HTTPINIT // start HTTP service, activate PDP context
OK
AT+HTTPPARA="URL","https://www.baidu.com" //access server and send file getbaidu.txt to server
OK
AT+HTTPPOSTFILE="getbaidu.txt",1,0 // access server and send file getbaidu.txt to server
OK

+HTTPPOSTFILE: 0,200,14615

+HTTP_PEER_CLOSED
AT+HTTPHEAD // read the HTTP server response header information.
+HTTPHEAD: DATA,773
HTTP/1.1 200 OK
Accept-Ranges: bytes
Cache-Control: no-cache
Connection: Keep-Alive
Content-Length: 14615
Content-Type: text/html
Date: Thu, 13 Sep 2018 05:14:30 GMT
Etag: "5b8641dc-3917"
Last-Modified: Wed, 29 Aug 2018 06:49:00 GMT
P3p: CP=" OTI DSP COR IVA OUR IND COM "
Pragma: no-cache

```

Server: BWS/1.1

Set-Cookie:

BAIDUID=A374BCFD28DFEEAF0BA0C4EEAC

77B0B0:FG=1; expires=Thu, 31-Dec-37

23:55:55 GMT; max-age=2147483647; path=;

domain=.baidu.com

Set-Cookie:

BIDUPSID=A374BCFD28DFEEAF0BA0C4EEA

C77B0B0; expires=Thu, 31-Dec-37 23:55:55

GMT; max-age=2147483647; path=;

domain=.baidu.com

Set-Cookie: PSTM=1536815670; expires=Thu,

31-Dec-37 23:55:55 GMT;

max-age=2147483647; path=;

domain=.baidu.com

Vary: Accept-Encoding

X-Ua-Compatible: IE=Edge,chrome=1

OK

**AT+HTTPTERM**

// stop HTTPS Service

OK

SIM  
Confidential